



Electronics Fabrication DC Power Supply



Cabinet Assembly Guidelines
Prepared by: M. LeNoble

hase 4-Cabinet Assembly bcit.ca/energy

## **Shop Safety**

### When working in the shop...

- Safety glasses must be worn at all times. (No exceptions)
- Closed toed shoes are to be worn.
- Wear close fitting clothing that cannot interfere with work.
- Tie back long hair so that it cannot interfere with work.



## **Cabinet Assembly**


- Phase 4 completes the DC Power Supply manufacture.
- The following tools are required for this phase of work:

Student Supplied	Shop Supplied
Safety glasses*	Screw drivers

<sup>\*</sup> Must be worn at all times when working in the shop.

Rotate the potentiometer shaft fully CCW. Mount the knob on to the shaft with the indicator stripe in the 7 o'clock position. Use a screw driver to secure the knob to the shaft. Ensure there is <u>uniform</u> clearance (about 1mm) between the front panel and the knob. Rotate the knob fully CW and confirm the indicator stripe is approximately in the 5 o'clock position.









Peel rubber feet off backing material to expose adhesive and affix one at each corner on the bottom of the chassis.



# **Cabinet Assembly**

- With exception of fastening the rear panel to the chassis, the DC Power Supply is complete.
- Arrange for the instructor to inspect the unit **before** attaching the rear panel.
- Attach the rear panel to the chassis using four sheet metal screws (supplied with cabinet) after the inspection is done.











## **Cabinet Assembly**

### Congratulations!

This concludes the manufacture of a DC Power Supply unit at BCIT.

#### **Power Supply Specifications**

Parameter	Specification
Input voltage	120V <sub>rms</sub>
Output 1	+5V, 1A, fixed
Output 2	-15V, 1A, fixed
Output 3	+15V, 1A, variable

<sup>\*</sup>Outputs may be configured in series to obtain higher voltages

Perform a final test on the completed unit using the Acceptance Test document.